
HENR Industrial Airtoo	PY ols at Worl	ן ה		LS	5			Models N-16X N-16R N-16T
Herritois com Herritois com Herritois com Herritois com		Genera	al Saf	iety ar Man		ntena	ance	
× + × ×	Model Number	Exhaust Direction	Tool Nose	Bore and Stroke	Weight	Length	Diameter	Air Consumption
+ + + + + + + + + + + + + + +	N-16X N-16R	Side Exhaust Side Exhaust	0.401 Round or 0.371 Hex	.63 Inch x 1.44 Inch (16 mm x 37 mm)	3.5 Lb. (1.6 Kg)	8.5 Inches (216 mm)	1.7 Inches (43 mm)	15 cfm (7.1 L/S)

THE HENRY TOOL CO., MANUFACTURED BY HENRY TOOLS 498 So. Belvoir Blvd., South Euclid, OH 44121 U.S.A. Ph: (216) 291-1011 or (800) 826-5257 • Fax: (216) 291-5949 or (800) 303-2800 Email: daviidh@msn.com • Website: www.Henrytools.com

General Operators Instructions and Service Manual



Hel Id. 1 (100-100, 116-10-19-10, 100-00) 1 (100-00-00) 498 So. Belvoir Blvd. South Euclid, OH 44221 U.S.A. 1011 01 (800) 865-5257 - Fax: (216) 201-5949 0r (800) 303 with Jamith Smeet Some - Wichelter , www.Henrytools.com

Ph:

General Operators Instructions and Service Manual

		Models N-16X						
-		N-16R N-16T						
	Genuine Henry Tool Parts	the air control valve. Never kink hose to stop air flow. E. Wear suitable goggles, mask, protective clothing or safety devices.						
PART NUMBER DESCRIPTION		F. Never use air to blow dust or chips from the hair, clothing, or safety devices. G. Never point the hose at anyone. Practical jokes with						
832078	SPRING	compressed air have caused many serious injuries. H. When using compressed air, see that no nearby workers are in line of airfl						
832142	LEVER	I. All compressed air supplies used for blowing must be equipped with 30 p.s.i. regulators.						
832171	VALVE BLOCK BUTTON	J. If working with or near compressed air tools, wear						
832196	VALVE	goggles. Never point the tool or air hose at any person. 1. Before starting work, learn what is underneath the						
832207	CAP SCREW	surface. If gas pipe, electric conduit, sewers, water mains, or other objects ar the area, get definite information of their location (blueprints, if possible) ar						
832225	LOCK RING	avoid them carefully.						
832293	BARREL	2. Wear safety shoes, goggles, and hard hats at all times. Also, wear ear protection.						
832377	PLUNGER	 Inspect the machine and equipment regularly, especially drill steel. Never u defective equipment. Check valves and connections carefully. Be especially careful when laying down the tool so that the trigger cannot be operated accidentally. Thoroughly examine the slope and flare for loose rock. Keep a good grip and watch your footing when tool is in use. 						
832453	TOOL NOSE(G-Rnd.)(.401)OPTIONAL							
832456	TOOL NOSE(G-Hex)(.371)OPTIONAL							
832462	TAPER TOOL NOSE (.401)OPTIONAL	7. NEVER POINT A PORTABLE POWER HAMMER AT ANYONE.						
832505	VALVE BLOCK(Inc's 832638)	 Before disconnecting a portable pneumatic tool, always turn the air off at base control valve. 						
832565	HANDLE LOCKING CLIP	If the job is near a sidewalk or other thoroughfare, place suitable screens to protect passersby from flying particles.						
832636	GASKET	PERSONAL PROTECTION						
832638	VALVE BLOCK PIN	There is no personal protective equipment that has proved to be effective against HAVS in stonemasons' yards. Anti-vibration gloves may be beneficial keeping hands warm but they are generally not effective at reducing vibratic at the low frequencies which are important in the development of VWF.						
832657	EXHAUST DEFLECTOR							
832802	BACKHEAD	However, it is important to keep hands warm, as this increases blood flow. The can be done by wearing						
832953	RETAINER	thermal gloves and providing localised heating and rest breaks in cold cond						
833550	EXHAUST DEFLECTOR SPRING	tions for workers to exercise and keep their hands warm. Exercising hands a fingers						
834782	VALVE	10. Never use compressed air to blow dirt, dust, or chips from hands, face, or clothing.						
841553	SCREEN BUSHING							
844302	O-RING							
844653	LEVER PIN							
/hen using con	npressed air							
. Use only sound	d, strong hose with secure couplings an are no sharp points on metal hose parts.							

D. Before changing one pneumatic tool for another, turn off

before turning on air.