

HENRY TOOLS

Industrial Airtools at Work

MODELS
4123GL
4123GL+6"

General Safety and Maintenance Manual



Model 4123GLS Die Grinder.



4123GLS+6" Model with super extended length spindle shown above.

SUPER HEAVY DUTY DIE GRINDER SERIES



Model Number	Exhaust Direction	Throttle Type	Speed	Power Output	Case Material	Weight		Length	Diameter	Air Consumption	Collet Size
						Aluminum	Steel				
4123G	Side (Side is Standard)	(L) Lever or (K) Safety Lever	15000 to 22000 R.P.M. (18000RPM is Standard)	0.9 H.P. 675 W	Steel or Aluminum	1.6 lb/0.7 Kg	2.0 lb/0.9 Kg	6.6 inch 167 mm	1.6 inches 41 mm	25cfm 11.8 L/S	1/8", 1/4", 5/16", 3/8"
4123G+6					1.8 lb/0.8 Kg	2.5 lb/1.1 Kg	12.3 inch 312 mm				

The Henry Tool Co., Manufactured by Henry Tools

498 So. Belvoir Blvd., South Euclid, OH 44121 U.S.A.


Ph: (216) 291-1011 or (800) 826-5257 Fax: (216) 291-5949 or (800) 303-2800

Email: daviidh@msn.com Website: www.Henrytools.com



MODEL
4123GL
4123GL+6"

4123GLS+6" Model with super extended length spindle shown above.



General Operators Instructions and Service Manual



4123GLS+6" Model with super extended length spindle shown above.

MODEL
4123GL
4123GL+6"

PART NUMBER	DESCRIPTION
209-1	COLLET NUT
209-1/8	1/8" INSERT
209-3/16	3/16" INSERT
209-1/4	1/4" INSERT
209-3/8	3/8" INSERT
400-G-26	THROTTLE LEVER
400-G-29	THROTTLE VALVE (INCLUDES 844302)
400-G-34	SPRING
400-2G	CYLINDER
400-6	BLADE (4 REQ.)
400-44	ROLL PIN
400-51	O-RING
402-126	SAFETY LEVER
402-127	SAFETY LEVER PIN
402-128	LOCKOUT LEVER
402-129	SAFETY LEVER SPRING
402-132	ALUMINUM CASE specify speed
402-132-S	"STEEL CASE (SPECIFY SPEED)"
402-134	MUFFLER
403-7	FRONT ENDPLATE
403-38	FRONT MOTOR RETAINER
404-9	REAR BEARING
404-19	REAR ENDPLATE
404-38	BEARING COVER
404-39	SNAP RING
410-G-17-S	"STEEL SIDE EXHAUST SLEEVE"
700-37	THROTTLE LEVER PIN
1100-672	STANDARD COLLET BODY
1100-678	EXTENDED COLLET BODY(+6)
4031-5A	ROTOR/SPINDLE
4031-5R	ROTOR SPACER
590031	FRONT BEARING
591106	SET SCREW (SPECIFY SPEED)
592016	SNAP RING
594016	O-RING
832636	GASKET
841552	3/8 NPT TO 3/8 NPT BUSHING

PART NUMBER	DESCRIPTION
841553	3/8 NPT TO 1/4 NPT BUSHING
844302	O-RING
869311	THROTTLE VALVE CAP
ASSEMBLIES	
PART NUMBER	DESCRIPTION
510206	REPAIR KIT Model 4123Series
402-26	SAFETY LEVER ASSY.
AA-402-132	ALUMINUM CASE ASSY.
AA-402-132-K	ALUMINUM SAFETY CASE ASSEMBLY.
AA-402-132-S	STEEL CASE ASSEMBLY
AA-402-132-SK	STEEL SAFETY CASE ASSY.
WRENCHES	
1100-068	11/16" WRENCH
1100-075	3/4" WRENCH

SAFETY

1. Before operation check spindle speed with a tachometer. If the RPM's exceeds the rated speed stamped on tool, servicing is required. For safety reasons and product liability prohibit any modifications to tools.
2. Inspect carbide burrs or mounted points for bends, chips, nicks, cracks or severe wear. If they have any of these problems do not use. On brushes check for loose wires that may fly off in operation.
3. Start new mounted points or burrs under a steel bench. Run at full throttle for one minute.
4. The 4123 series die grinders are intended for use with Burrs/Mounted Stones of shank size 1/8 inch, 1/4 inch, 5/16 inch, 3/8 inch, 3mm, 6mm, 8mm. only. They are NOT guarded for type 1 wheels. If you have a type 1 wheel application, please purchase a different model tool.
5. At least one-half of the mandrel length (i.e. mounted wheel, burr, etc.) must be inserted into the collet. Secure collet chuck tightly.
6. Safety levers are available from the manufacturer (402-26).
7. Before mounting or removing a Burr/mounted point disconnect the grinder from air supply. Wear safety goggles and other protective clothing (when necessary).(See regulations.)
8. Properly maintained air tools are less likely to fail or cause accidents. If tool vibrates or produces an unusual sound, repair immediately.



MODEL
4123GL
4123GL+6''

4123GLS+6'' Model with super extended length spindle shown above.

LUBRICATION

Lubricate the motor with an air line lubricator, using a light air motor oil. Adjust the lubricator to dispense one drop per cycle or three drops per minute.

CAUTION Do not use substitutes for oil and grease. This could result in damage to the tool.

MAINTENANCE

1. Proper and continuous lubrication.
2. Blow out air hose to assure a clean air supply.
3. Be sure the air filter and line lubricator are clean.
4. Fill the line lubricator before operation.
5. Place a few drops of oil into the air inlet of the tool before attaching the air line.
6. Use moisture separators to remove water from the air line.
7. An air line filter-regulator-lubricator should be located as closely as possible to the tool.
8. Keep screen handle bushing in tool.

WARNING: Disconnect the air supply hose before servicing the tool.

Disassembly

1. Secure tool in vise vertically with output of tool oriented toward upward direction. Clamp onto the flats toward the rear of the motor housing.
2. Unscrew motor retainer (403-38) from motor housing(402-132). Lift off exhaust deflector(410-G-17-S) and o-ring (400-51)if worn from motor housing. Remove motor assembly from housing.
3. Secure motor assembly into vise vertically with output in the downward direction. Clamp onto flats on the collet body (1100-672).
4. Remove snap ring (404-39) from rear endplate (404-19) with use of snap ring pliers.
5. Lift out bearing cover (404-38) and o-ring (594016).
6. Remove snap ring (592016) from groove of rotor (4031-5A).
7. Using a soft-jawed vise. Secure motor assembly into vise vertically with output toward downward direction. Clamp lightly the outside diameter of the cylinder (400-2G) and endplate (404-19).
8. Use a 3/16" punch to tap spindle out of rear bearing (404-9). Do NOT drop the motor assembly when it is free. Remove from vise.
9. Use a small punch to press the rear bearing from the rear endplate.
10. Remove the 5 blades (400-6).
11. With soft jaws still in vise, clamp firmly onto rotor (4031-5A) with output toward upward position. Remove collet body (1100-672) (right hand thread). Remove from vise.
12. Support the rotor assembly on a suitable drill block. Press the spindle through the front bearing

assy. using an arbor press. Use a small punch to remove front bearing (590031) from front endplate(403-7).

13. (OPTIONAL STEP): To check throttle valve unscrew throttle valve cap (869311).

14. 14. (OPTIONAL STEP): Lift out valve spring (400-G-34) and throttle valve (400-G-29). Remove and replace o-ring (844302) if cracked or worn.

Assembly

1. Be sure that all parts are clean.
2. Press bearing (590031) into recessed area of front endplate (403-7).
3. Support the front bearing assembly on a suitable drill block. Press the rotor (4031-5A) into the rear of front endplate and through front bearing.
4. With soft jaws on vise, clamp firmly onto rotor (4031-5A) with output toward upward position. Install collet body (1100-672) (right hand thread). Remove rotor from vise.
5. Secure motor assembly into vise vertically with output in the downward direction. Clamp onto flats on the collet body (1100-672).
6. Place five blades (400-6) into blade slots.
7. Slip cylinder (400-2G) over rotor and onto endplate. The small pin on face of cylinder should face toward rear to tool.
8. Place rear endplate (404-19) onto cylinder. Locate the pin of the cylinder into the small hole of the rear endplate.
9. Press bearing (404-9) into rear endplate with a suitable bearing driver.
10. Install retaining ring (592016) into groove on spindle with snap ring pliers.
11. Place o-ring (594016) and bearing cover (404-38) into rear endplate.
12. Install snap ring (404-39) into groove of rear endplate.
13. Secure motor housing (402-132) in vise vertically with output of tool toward upward direction. Clamp onto the flats toward the rear of the motor housing.
14. Place o-ring (400-51), exhaust screen (402-134) and exhaust deflector (410-G-17-S) onto motor housing.
15. Slide front motor assembly into motor housing. Install motor retainer (403-38). Tighten assemblies together.
16. Check the operating speed with a reliable tachometer. The speed must be at or below the stamped speed on the tool.

FAULT	CAUSE	SOLUTION
Insufficient Power	Air pressure too low	Minimum air pressure <i>should</i> be 90 PSI for maximum performance
	Restriction in air hose	Remove bends or other restrictions
	Hose I.D. is too small	Use required hose I.D.
	Worn vanes	Exchange vanes (400-6)
Machine does not start	Screen Support clogged	Clean screen support or exchange with new one
	No air, shut-off valve is closed.	Open shut-off valve
Grinder does not want to stop	Worn vanes due to lack of oil or vanes are jammed	Exchange vanes . (cylinder might also be worn out)
	Worn O-Ring	Replace o-ring in handle (844302) for example.
Spindle wobbles or vibrates.	Bearings worn out . Danger!!	Disconnect tool from the air supply. <i>Immediate</i> servicing is required.