HENRY AIRTOOLS

American Made Industrial Tools

MODELS 400GE 400GES



General Safety and Maintenance Manual

1.2 H.P. SIDE EXHAUST DIE GRINDER







1.2 H.P. SIDE EXHAUST DIE GRINDER


Model	Exhaust	Throttle		Power	Case	We	ight			Air	
Number	Direction	Type	Speed		Material	Aluminum	Steel	Length	Diameter	Consump- tion	Collet Sizes
400GE	SIDE	(L) Lever	18000 R.P.M	1.2 H.P.	Alum.	-	2.6 lb. (1.2 Kg)	7.52 Inch (191 mm)	1.6 inches	35 CFM (16.5 L/S)	1/4 Inch Collet
400GES	EXHAUST		20000 R.P.M	900 W	Steel	1.8 lb. (0.8 Kg)	2.6 lb. (1.2 Kg)	7.52 Inch (191 mm)	41.1 mm	(16.5 L/S) Max.	3/8 Inch Collet

THE HENRY TOOL CO., MANUFACTURED BY HENRY TOOLS

498 SO. BELVOIR BLVD., SOUTH EUCLID, OH 44121 U.S.A.

PH: (216) 291-1011 OR (800) 826-5257 • FAX: (216) 291-5949 OR (800) 303-2800

EMAIL: DAVIIDH@MSN.COM • WEBSITE: WWW.HENRYTOOLS.COM



PART NUMBER	DESCRIPTION
H17S	Side exhaust Deflector
H51	O-Ring
H130-S	Steel Motor Case
H130	Aluminum Case
H26	Lever
841552	Bushing

PART NUMBER	DESCRIPTION
H37	Roll Pin
H32	O-Ring
H41A	Throttle Valve
400-G-34	Spring
320-9R	O-Ring
320-9F	Cover

144

Revised: 04/13/2024

WWW.HENRYTOOLS.COM

General Operators Instructions and Service Manual







Model 400GES Aluminum Side Exhaust Die Grinder.

MODELS 400GE 400GES

PART NUMBER	DESCRIPTION
592067	Snap Ring
HC-2	Collet Nut
HC-3-1/4"	1/4" Collet Insert
HC-3-3/8"	3/8" Collet Insert
H38	Motor Retainer
H209B	Collet Body
H11	Bearing
H7-S	Front End Plate
H60	Rotor Blade(5 are Req'd)
HB50	Rotor/Spindle
H2	Cylinder
H44	Cylinder Pin
H3-S	Rear EndPlate
H9	Bearing
592016	Snap Ring
H23	O-Ring
H24	Bearing Cover
H25	Snap Ring
AA-H126	Safety Lever Assembly (COMPLETE)
H127	Safety Latch
H126	Safety Lever
H128	PIN
H129	Spring
1100-063	5/8" Wrench

PART NUMBER	DESCRIPTION				
1100-081	13/16" Wrench				
G50R	Spacer				
400GE REPAIR KIT					
510284 Repair Kit					
Includes:					
H11	Front Bearing				
H60	Rotor Blade				
Н9	Rear Bearing				
592016	Snap Ring				
H23	0-Ring				
H24	Bearing Cover				
H25	Snap Ring				
H32	0-Ring				

GRINDER SAFETY

ALWAYS COMPLY WITH:

- General Industry Safety & Health Regulations, Part 1910, OSHA 2206, available from: Sup't of Documents; Government Printing Office; Washington DC 20402
- Safety Code for Portable Air Tools, ANSI B186.1 available from: American National Standards Institute, Inc.; 1430 Broadway; New York, NY 10018
- 3. State and Local regulations.
- 4. Portions of the above codes and regulations are listed below for quick reference.

THESE EXCERPTS ARE NOT INTENDED TO BE ALL INCLUSIVE - STUDY AND COMPLY WITH ALL REGULATIONS!

- 1. Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- ing any maintenance on this tool.

 2. After mounting a wheel or other abrasive accessory, the Grinder shall be run in a protected enclosure, at gradually increasing speed, for at least 60 seconds. When starting work with a cold wheel, apply it gradually to the workpiece until it becomes warm. Do not continue to use a grinder if:
 - The speed rating of the accessory is less than the speed of the grinder
 - If tool vibrates repair immediately.